



EPIC 180 BUFFET / EPIC 180 SIDEBORD / EPIC 180 APARADOR / EPIC 180 CREDENZA

REF: 56104


Notice de montage / Assembly Instructions / Instrucciones de montaje / Istruzioni di montaggio



< 45 kg



60'



FRANCAIS

- > Consacrez quelques minutes à la lecture de cette notice de montage avant de suivre pas-à-pas les différentes étapes d'assemblage
- > Vérifiez que vous disposez de toutes les pièces et accessoires nécessaires au montage de votre meuble avant de jeter tout emballage
- > Effectuez votre montage sur une surface plane
- > Ne serrez pas les vis au maximum avant la fin du montage
- > Jetez les pièces supplémentaires et gardez les hors de portée des enfants

ENGLISH

- > We suggest you spend a short time reading through this leaflet and follow the simple step-by-step assembly instructions.
- > Do not discard any of the packaging until you have checked that you have all the parts and the pack of fittings.
- > Assemble this product on a flat surface.
- > Assemble all parts loosely before tightening any bolts
- > Discard all extra fittings and keep fittings out of reach of children.

ESPAÑOL

- > Dedique unos minutos a la lectura de estas instrucciones para seguir paso a paso las etapas de montaje.
- > Compruebe que dispone de todas la piezas y accesorios necesarios al montaje antes de tirar los embalajes
- > Efectue el montaje sobre una superficie plana
- > No apriete los tornillos al maximo hasta el final del montaje
- > Mantener las piezas que sobren fuera del alcance de los niños hasta tirarlas

ITALIANO

- > Leggere attentamente le istruzioni di montaggio prima di cominciare
- > Prima di buttare il cartone d'imballo verificare scrupolosamente che nessun elemento né accessorio sia mancante
- > Effettuare il montaggio su una superficie piana
- > Non serrare le viti al massimo prima della fine del montaggio
- > Buttare i pezzi supplementari e tenerli fuori portata dei bambini



FR


















CARTON



PAPIER






A  (D8*40)	B  (34)	C  (D15)	D  (D20)	E  (D5*50)
6PCS	6PCS	6PCS	6PCS	6PCS
F  (M8, 50*50)	G  (D4,5*16)	H  (85*40*20)	I  (D3,5*12)	J  (D5)
5PCS	20PCS	2PCS	4PCS	8PCS
K  (D17)	L  (safety strap)	M  + screw D3*20	N  (paraffin)	O  (D3,5*25)
4PCS	1PC	12PCS	1PC	2PCS
P  (HEX 3)	Q  (HEX 4)			
1PC	1PC			




1



FR



2




FR



+




3




FR



4



5



FR



CARTON







PAPIER







6

NB! A=B


I



III




7




FR



8



9




place heavy items on or inside the cabinet.

NB! In 7 if you decide to use the fifth leg, turn the cabinet on its legs and as a 2, adjust the middle leg 1 to stabilise 9 furniture.

OPCIONAL: Utilice la quinta pata del medio (9) sólo si planea colocar artículos pesados sobre o dentro del gabinete.


NB! If you decide to use the fifth leg, turn the cabinet on its legs and as a 2, adjust the middle leg 1 to stabilise 9 furniture.




FR



10



11



*Doors should be worked in before using

- Move doors back and forth 15x before attaching knobs

Maintanace:

- Rub candlewax or paraffin wax on the bottom of the groove
- Move doors back and forth 15x

*Les portes doivent être travaillées avant utilisation

- Déplacez les portes d'avant en arrière 15x avant de fixer les boutons

Maintanace:

- Frottez la cire de bougie ou la cire de paraffine au fond de la rainure
- Déplacez les portes d'avant en arrière 15x

*Las puertas deben trabajarse antes de usar

- Mueva las puertas hacia adelante y hacia atrás 15x antes de colocar las perillas

Mantenimiento:



- Frotar cera de vela o cera de parafina en la parte inferior de la ranura
- Mueva las puertas hacia adelante y hacia atrás 15x



FR



12



Wood




Brick

Cavity

If you are fixing the cabinet to a wood substrate, we advise that chipboard is not used as the screws can easily pull away from the structure.

Use appropriate wall plugs. Please ensure that your wall is of sound structure. If in doubt please seek professional advice.



Special toggle wall plugs are needed. Seek expert advice.



WARNING

Serious or fatal crushing injuries can occur from furniture tipover. To prevent this furniture from tipping over it must be permanently fixed to the wall with the included wall attachment devices. Fastening devices for the wall are not included since different wall materials require different types of fastening devices. Use fastening devices suitable for the walls in your home. For advice on suitable fastening devices, contact your local specialized dealer!

13



FR



14

